# REAFREE® 6489-TS

**POWDER COATINGS / HYBRID** 

**TECHNICAL DATA SHEET** 

(RS720)

April 2014

### Product Application details

Saturated carboxylated polyester suitable for the formulation of decorative and protective thermosetting tribochargeable powders in combination with epoxy resins. Gas oven stabilised. General purpose polyester.

TMA free type.

## Performance Benefits

- Excellent overbake resistance, also in gas-oven applications.
- Very good flow.
- High salt spray resistance.
- Good mechanical properties.
- Good recoatability.
- Tribochargeable.

## Polymer Type

Saturated Carboxylated Polyester Resin

## **Sales Specifications**

Colour (50%), (ASTM D-1544)	3 max
Acid value, mg KOH/g (ASTM D-1639)	32 - 37
Viscosity 165°C, Pa.s (ICI – DIN 53229)	24 - 30

## Other Characteristics<sup>1</sup>

Appearance	Pale granules
Glass Transition T, °C (DSC - Tg)	approx 59

1 The data provided for these properties are typical values, intended only as guides, and should not be construed as sales specifications

#### **Curing Conditions**

10 minutes at 180°C (oven temperature)

### Recommended Mixing Ratio

REAFREE 6489-TS / Epoxy: 70/30

#### **Starting Formulation**

REAFREE 6489-TS	438
Titanium Dioxide(1)	334
Epoxy resins(2)	188
REAFREE F3300-A15	37
Benzoin	3

## Formulation

**Guidelines** 

(1) Kronos 2160

(2) Araldite GT-7004 (Huntsman) DER 663 UE (Dow Chemical) Epikote 3003 (Resolution)

#### **Application / Extrusion Conditions**

Extruder:

Torque:
40%
Speed:
200 rpm
Extrusion temperature:
80°C
Spraying Gun:
Application voltage:
Test substrate:

BUSS PCS-30
Geman PCS-30
Geman

#### **Coating Properties**

Film thickness 60-80 microns
Gloss 60°, (ASTM D-523-60E) Over 94%
Cupping test, (DIN 53156) Over 8 mm
Direct Impact, (ASTM D-2794) Over 80 Kg.cm
Reverse Impact, (ASTM D-2794) Over 80 Kg.cm
Conical mandrel, (ASTM D-522) 100%

Conical mandrel, (ASTM D-522) 100% Adhesion, (DIN 53151) Gt0



steel 1 mm

Product Safety	Please refer to the corresponding Safety Data Sheet.
<b>Delivery form</b>	Granules. White opaque polyethylene bags of 25 Kg. One Ton pallet shrink – wrapped.
Storage & Handling	The resin in its original unopened bags is stable for more than three years, stored in a dry place at temperature below 30°C. Avoid direct sunlight.

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.

The products described in the document are not Medical grades designated for Medical Device applications.

Arkema has implemented an internal Medical Policy regarding the use of Arkema products in Medical Devices applications. Arkema has designated Medical grades to be used for Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications. In addition, except for limited cases as determined by the Medical Device Policy, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days.

For any use of Arkema's product in Medical Device applications, please contact Arkema's sales network.

